


Use the keypad to control the room



When leaving the classroom, please:

- **Turn system OFF – Press and HOLD Projector On/Off button**
(System will be non-responsive for 60-90 seconds as projectors cool)
- **Log out of the room computer** (computer should always remain on)

(additional detail and help on reverse)

AUX: Connect and Display your Laptop, Smartphone or Tablet

The **AUX input plate** allows the user to connect an HDMI-compatible device and/or analog audio source. Common cables and adapters are available in the room to connect your device, though you may wish to purchase your own set.

*We encourage you to **plan ahead** and be familiar with how your device connects to HDMI. Please feel free to call us for help.*

CAMERA: Display the Document Camera

1. Swivel the document camera arm toward you
2. Raise the camera arm - camera will automatically turn on
3. Press CAMERA on keypad and adjust image as needed:
 - Rotate ZOOM wheel to zoom in and out
 - Press FREEZE to retain current image – press again to release
 - Press LIGHT to turn the lamp on/off
 - Press FOCUS to turn auto focus on/off
4. When finished, lower camera arm (turns OFF) and swivel away



Kensington Remote: Provides remote control and laser pointer

Works with most programs (like PowerPoint) to control slides

- Top button beams the laser pointer
- Right button advances to the next slide or page
- Left button returns to the previous slide or page
- Bottom button blanks the screen (PowerPoint) – press again to release

Placing the USB receiver back in the unit turns unit off and saves batteries.

This is not a flash drive; please do not walk off with the USB receiver.

