Presentation Classroom Instructions – HSFAC 160

Instructions available online at www.baylor.edu/astc/instructions

HSFAC 160 is equipped with a flat-screen TV.

Television
- Turn on the TV by pressing the green POWER button on the Sony TV remote.

Connecting via the Wall Plate: VGA
- A wall plate has been provided to the left of the TV to connect your laptop or other peripheral device.
- For laptops, plug in to the VGA and audio cords.
- If no image is being displayed:
    - Check that the TV input is set appropriately by pressing the INPUT button on the TV remote, scrolling to the device using the up/down arrow buttons, and select using the center button on the remote.
- The TV can be used as a second monitor for your computer, or to mirror your computer. This setting can be changed on a Mac in the System Preferences, under Displays, and in the Control Panel, under Display on the PC.

Connecting via the Wall Plate: HDMI
- You may alternatively connect to the TV via the HDMI connection on the wall plate, with a user-provided HDMI cable. Many Blu-Ray and DVD players have HDMI ports, and with an appropriate adapter, laptop computers can also make use of this connection.
- To select the HDMI input, press the INPUT button on the TV remote and select the HDMI input using the up/down arrow buttons. Select that input by pressing the center button on the remote.

POWER button

INPUT button

Center button

Volume Controls
Use the VOLUME + / - button on the remote to control the TV speaker volume. A mute button is provided below the volume button.

Volume controls

To Shut Down:
Please turn off the TV when finished, by pressing the green POWER button on the remote.

For immediate assistance or to report a problem, call/text 254-307-1614 (Classroom Technology Services).
For other questions, suggestions, or training, email ASTC@baylor.edu (Arts & Sciences Technology Center).
Page 1 of 1 / Last Updated: 12/15/2011 by Stephen Rylander