

Use the TV remote to control the room

Control Options

PRESS to turn television ON and OFF

Point remote directly at each TV to control that TV

Adjust VOLUME

Problems: Check volume and mute control on computer or application

The system is designed for sound to come from the LEFT TV only



Source Options

Select SOURCE

PC is selected by default

The image from both monitors will be duplicated on the TVs

When leaving the classroom, please:

- Turn TVs OFF – Press POWER button on the TV remote while pointed at each TV
- Log out of the instructor computer (computer should always remain on)