

Presentation Cart Instructions – Biology Cart 2 (BSB A214)

Instructions available online at www.baylor.edu/astc/instructions

Biology Cart 2 is equipped with a projector. Plug the extension cord on the cart into a power outlet, and make sure the surge protector is turned on.


Projector

The projector may be controlled with the remote control or the buttons on top of the projector.

1. Align the projector at the front of the room toward the wall or projection screen.
2. If present, remove the lens cap from the projector.
3. Plug the VGA, audio, and network cables on the cart into your laptop or mobile device.
4. Press the ON button on the remote (*Figure 1*) or the STANDBY/ON button on the projector (*Figure 2*) to power the projector on.



(Figure 1)



(Figure 2)

5. In approximately 25 seconds, the projector will warm up and project on to the screen.
6. Adjust focus using the ring in front near the lens.
7. If no image displays:
 - Press the COMPUTER button on the remote to select the input, or press INPUT on the projector until COMPUTER is highlighted and then press ENTER.
8. Control volume using the volume control knob on the external speakers.

Shut Down

1. To power the projector off, press the STANDBY button on the remote or the STANDBY/ON button on the projector twice. **Please do not unplug the cart until the projector fan goes off. This will take about 90 seconds.**
2. Roll up the power and network cords and neatly store on the cart for the next user.